



Mower Deck Assembly



Mower Deck Assembly

Ref.	Parts NO	Description	Ref.	Parts NO	Description
4	4211090	Discharge Chute	40	5001090	Deck Belt Tension Arm
5	5001007	Torsion Spring	41	5201077	Bearing Spacer
6	2802008	Bolt M8×160	42	5201064	Tension Pulley
7	B97.1-10	Flat Washer M10	43	5201078	Bearing Spacer M10
8	B6182-10	Locknut M10	44	5201062	Tension Pulley Brace
9	T001121	Floating Roller	45	B5787-1030	Hex Hd. Bolt M10×30
10	T001122	Bolt Sleeve	46	4211002	Blade Drive Belt
11	B5782-880	Bolt M8 X80	47	4211040	Mower deck Weldment
12	B97.1-8	Flat Washer M8	48	B5787-10110	Bolt M10X110
14	4806002	Pin	49	B5787-1070	Bot M10X70
15	5001331	Bushing 1	51	5001301	Blade Washer
16	5001332	Bushing 2	52	6011143	Spindle Shaft
17	B6182-8	Nut M8	53	B6173-20	Nut M20X1.5
18	5001304	Front Deck Support Rod	54	5201048	Washer (2)
19	5001303	Rod Pivot Bushing	55	4211105	Blade Pulley
21	B6182-12	Nut M12	56	5201044	Upper Dust Guard
22	5201291	Bearing Cover	57	B276-6205RS	Bearing 6205-2RS
23	5201012	Idler Pulley	58	5201049	Spindle Bearing Spacer
24	B276-6203RS	Bearing6203-2RS	59	5201050	Spindle Housing
25	B893.1-40	Snap Ring M40	60	B893.1-52	Snap Ring M52
26	5201011	Idler Spacer Bushing	61	5201043	Lower Dust Guard
27	5001005	Deck Stabilizer Rod	63	B1096-0622B	Key B6×25
28	5001006	Washer M12	64	4211101	Blade
30	B5782-8120	Bolt M8X120	65	5201042	Disk Spring Washer M16
31	5001008	Deck lift Rod	66	B5787-16060	Bolt M16X60
33	5001083	Washer M10	67	4211100	Spindle Assembly
34	3301003	Olite bronze bushing	280	B6172-12	Bolt M12
35	B1152-6	Grease Fitting M6	281	5201010	Tension Pulley Assembly
36	5001081	Pivot Tensioner Mount	282	5001080	Tension Pulley Assembly
37	4211004	Pump Tension Pulley	373	T001120	Anti Scalp Roller
38	GB5787-1035	Bolt M10X35	374	5001330	Anti Scalp Roller
			1	4211110	Belt Cover


Frame Assembly



Frame Assembly

Ref.	Parts NO	Description	Ref.	Parts NO	Description
17	B6182-8	Nut M8	90	5002308	Stabilizer Arm Mount
50	B801-820	Bolt M8×20	91	5002020	Caster Pivot Cap
68	5002335	Right Beam	92	B6182-16	Nut M16
69	5002355	FOOT PLATE	93	5002091	Spring washer M16
70	4212001	Panel	94	B297-32922	Bearing 329/22
71	B5783-816	Bolt M8×16	95	B9877.1-28407	Grease Seal 28×40×7
72	B93-8	Washer 8	96	5002095	Caster Wheel Yoke
73	B97.1-8	Washer 8	97	B5782-12150	Bolt M12×150
74	5002321	Front Supporting Plate	98	5002092	Caster Wheel Bushing
75	5002017	Front RH Tank Bracket	99	5002103	Wheel Bearing
76	5002322	Middle Cross Beam	100	5002102	Rim 5×3
77	5002016	Front LH Tank Bracket	101	B1153-645	Grease Fitting 45°M6
78	5002310	Rear Supporting Plate	102	5002101	Tire 11×4
79	B1152-8	Grease Fitting M8*1	104	5002007	Foot Plate Pivot Bushing
80	B5783-820	Bolt M8×20	107	B5783-825	Bolt M8X25
81	5002323	Rear Guard	121	B801-616	Bolt M6×16
82	5002307	Front Bump	124	B6182-6	Nut M6
83	5002325	Front Beam	249	5201003	Bumper Block
84	5002330	Left Beam	250	B70-630	Screw M6×30
85	5002309	Rear LH Tank Bracket	251	5002365	Deck Stop
86	5002380	Engine Base Weldment	253	5002390	Wire rod welding
87	5002085	Frame Brace	288	B6182-12	Nut M12
88	4LZ2.16.4-04	Rubber Bushing M29	307	5002100	Front Wheel
89	5002336	Battery Tray	309	5009026	Fixed Plate


Control Assembly



Control Assembly


Ref.	Parts NO	Description	Ref.	Parts NO	Description
2	B97.1-6	Flat Washer M6	136	5002131	Left Control Link
8	B6182-10	Locknut M10	137	5002009	Axle Pin 2
17	B6182-8	Locknut M8	138	B6170-6	Nut M6
35	B1152-6	Grease Fitting M6	139	B93-6	Lock Washer M6
50	B801-820	Hex Hd Bolt M8×20	257	5002270	Washer
72	B93-8	Washer M8	258	5002260	Brake Tension Spring
73	B97.1-8	Flat Washer M8	260	5002111	Pivot Shaft
80	B5783-820	Bolt M8×20	261	5002347	Stop Bracket RH Torsion Spring
103	XSZ56-1-17	Pin	262	5002118	Torsion Spring RH
105	5002145A	Right Handle	263	B2685-121618	Oilite Bronze Bearing 12×16×18
106	5002034	Handle Grip	264	B861.1-6	Washer M6
107	B5783-825	Hex Hd Bolt M8×25	265	5002120	Pivot Block Weldment
108	5002343	RH Handle Mount ASM	266	5002344	Right Brake Panel
109	5002138	RH Control link	267	5002112	Operating Pin Roll
110	5002008	Shoulder Pin	268	2806061	Washer M12
111	B6170-8	Locknut M8	269	B879-520	Pin 5×20
112	5002134	Neutral Buckle M8	270	5002113	Handle Mount Block
113	5002135	Screw M8	271	5002114	Spring
114	SIBJK 8T	Rod End Bearing	272	B308-4	Steel Ball SR4
115	B5783-840	Hex Hd Bolt M8×40	273	2800006	Washer M8
116	5205012	Damper	274	5002345	Stop Bracket LH Torsion Spring
122	5002350	Control Panel Mount	275	5002117	Torsion Spring LH
124	B6182-6	Locknut M6	276	5002342	Left Brake Panel
125	5002031	Right Switch Bracket	287	5000002	Seat Pull Rod
126	5002210	Brake Cable	400	5208070	Ignition Switch
127	5002005	Cable Mount Bracket	401	5002220	Choke Cable
128	5002026	Brake Adjustment Link	402	3306030	Knob
129	5000090	Seat	403	3336019	Throttle Control Assembly
130	5000081A	Seat Plate	404	B801-616	Hex Hd Bolt M6×16
131	B5783-1025	Bolt M10×25	405	5208022	Blade Control Switch
132	3300106	Bolt 5/16-18UNC	406	5204015A	Three Way Valve
133	5002140A	Left Handle	407	B6182-6	Locknut M6
134	5002341	LH Handle Mount Assembly			
135	5002032	Left Switch Bracket			

Engine System




Ref.	Parts NO	Description	Ref.	Parts NO	Description
8	B6182-10	Locknut M10	157	5203405	Key 6.35×25
12	5201061	Washer	158	4804005	Clutch
13	B5782-10100	Bolt M10X100	160	5203412	Bolt 7/16-20UNF×3
17	B6182-8	Nut M8	161	5002160	Tension Pulley Assembly
73	B97.1-8	Washer 8	162	4806004	Idler Spring
107	B5783-825	Bolt M8×25	163	5002004	Pump Drive Belt
140	3302190	Three-Arm Knob	164	5208203	hook rod
141	5002385	Fan Cover	165	B5782-1060	Bolt M10X60
142	B62-6	Wing Nut M6	166	5002175	Tension Idler
143	3203004	Battery Strap	167	B276-6303RS	Bearing 6303-2RS
144	5208002	Battery 12V 33AH	168	B893.2-47	Snap Ring M47
145	5203045	Spring Cover	169	5002161	Tension Pulley Spacer
146	5002022	Spring	170	5002165	Pump Tension Arm
147	5203435	Bolt 3/8-16UNCX1-1/2	171	5002164	Tension Idler Spacer M10
148	5002371	Clutch Stop Spacer	172	B2685-202420	Bearing 20×24×20
149	5203408	Washer	173	5002163	Pivot Bushing
150	5203411	Clutch Stop Strap	174	3307004	Washer M11
151	5203410	Rubber Washer M17	175	4210011	KAWASAKI FR600V Engine
152	5203409	Bushing	187	3601020	Clamp
153	B5782-8100	Bolt M8×100	273	2800006	Flat Washer M8
154	B5783-835	Hex Hd Bolt M8×35	285	5203420	Fuel Outlet Assembly
155	3607002	Engine Shaft Spacer	286	3302058	Washer M10
156	5002152	Pump Drive Pulley	290	5002268	Muffler


Drive System















Ref.	Parts NO	Description	Ref.	Parts NO	Description
1	B5783-616	Hex hd bolt M6×16	177	5002012	Fixed Plate, Front
2	B97.1-6	Flat Washer M6	178	B5782-1050	Bolt M10×50
7	B97.1-10	Flat Washer M10	179	5002023	Left Pressure Relief Rod
17	B6182-8	Locknut M8	180	B93-10	Washer M10
62	B5782-860	Bolt M8×60	181	5002011	Right Drive Axle
73	B97.1-8	Flat Washer M8	182	5002081	Axle
103	XSZ56-1-17	Hair Pin	183	5002010	Left Drive Axle
107	B5783-825	Hex Hd Bolt M8×25	184	5000001	Nut 1/2-20UNF
117	B5782-870	Bolt M8×70	185	4200350	Rear wheel18×7.5-8
118	2802183	Washer M6	186	5002013	Outer Axle Mounting Bracket
123	6012005	Spacer Bushing	246	5002014	Left Inner Axle Mounting Bracket
124	B6182-6	Locknut M6	247	5002015	Right Inner Axle Mounting Bracket
131	B5783-1025	Bolt M10×25	273	2800006	Flat Washer M8
139	B93-6	Lock Washer M6	380	B5782-8130	Bolt M8×130
165	B5782-1060	Bolt M10×60	381	4200352	Rim
176	5002024	Right Pressure Relief Rod	382	4200352	Tire 18×7.5-8



Fuel Tank System




Ref.	Parts NO	Description	Ref.	Parts NO	Description
410	B5783-816	Hex Hd Bolt M8×16	417	3307025	Hose Clamp
411	B93-8	Split Lock Washer M8	418	5000103	Fuel Pipe 450
412	B97.1-8	Flat Washer M8	419	5204015A	Three Way Valve
413	4805005	Gas Cap	420	5000104	Fuel Pipe 750
414	5000101	Right Fuel Tank	421	5000105	Fuel Pipe1150
415	3307023B	Fuel Tank Bushing	422	5000102	Left Fuel Tank
416	5204016	Right-Angle Connector			

 220	 221	FUSE BLOCK 8509 222	 223	 233	 236				
 245	 233	 229	 228	 230					
	 224	 239		42 8513 232					
 238	 241	 225							
 235			 234						
VIPER 226	WORLDLAWN POWER EQUIPMENT, INC. <table><tr><td>MODEL</td><td>SERIAL</td></tr><tr><td></td><td>P</td></tr></table> MADE IN CHINA 231		MODEL	SERIAL		P	EMISSION CONTROL INFORMATION JIANGSU WORLD PLANT-PROTECTING MACHINERY CO.,LTD THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARDS EQUIPMENT FAMILY NAME:JWVPRHE0002 226		
MODEL	SERIAL								
	P								
 242	 243		Worldlawn Power Equipment 244  237						

Decal



Ref.	Parts NO	Description	Ref.	Parts NO	Description
220	8312	Decal, Ignition	233	8508	Motion Control LH
221	8314	Decal,throttle control	234	8307	Discharge Warning
222	8509	Fuse Decal	235	8519	Operational Warning
223	8507	Decal, Throttle	236	8512	Motion Control RH
224	8318	Decal,Rear Guard	237	8325	Decal,Danger Blades
225	8303	Caution Guard	238	8515	Rotating Parts
226	8550	Viper LOGO	239	8501	Decal
228	8517	Cutting Height Locator	241	8511	Decal,Deck Belt Routing
229	8603	Transaxle Release LH	242	8308	Decal,Shield Warning4
230	8604	Transaxle Release RH	243	8305	Decal,Danger Foot Plate1
231	8046	Serial Number Plate	244	8341	Worldlawn logo
232	8381	42 size decal	245	8510	Decal,Cutting Height Outer
233	8985	WORLDLAWN LOGO			



Ref.	Parts NO	Description	Ref.	Parts NO	Description
208	5008003	Plunger Switch	215	5008005	Nut5/16-24UNF
209	5208070	Ignition Switch	216	2808107	Relay Cable Cover
210	5208022	Blade Switch	217	3312032	Battery Boot(Positive)
211	5208007	Fuse 20A	218	3312031	Battery Boot(Negative)
212	5208011	12V Delay	219	5008021	Wiring Harness
213	3WPZ500-050025	Start-up Relay	259	5008012	Relay plate
214	5008004	Positive Cable	310	5208072	Key
299	5008008	Negative Cable	311	5208071	Switch
298	5008006	Wire to Motor			

